















ML23

ASSEMBLY MANUAL

ACCESSORY LIST



A01  B0502 12x	A02  B0504 12x	A13  B0105 4x	A12  B0305 8x	A28  B0318 30x
A70  B0501 12x	A15  B0101 4x	A10  B0301 24x	A41  B1601 4x	 B0503 12x
A08  B0317 2x	A41  B1303 2x	A09  B0306 2x		

GENERAL VIEW

